



## INSTRUCTION MANUAL

# UNIVERSAL INJECTOR SHAFT CLEANING KIT

ART.-NO. **9038100**

Includes:

Module 1	Brushing	Art.-Nr. 9038010
Module 1.1	Brushing Plus	Art.-Nr. 9038011
Module 2	Milling	Art.-Nr. 9038020
Module 3	Extracting the Sealing Ring	Art.-Nr. 9038030



## CONTENTS

<b>Universal Injector Shaft Cleaning Kit .....</b>	<b>4</b>
<b>Safety notice .....</b>	<b>6</b>
<b>1. Preparation.....</b>	<b>7</b>
<b>2. Module 1 - Brushing.....</b>	<b>8</b>
2.1 Cleaning the bore to the combustion chamber .....	8
2.2 Closing the bore to the combustion chamber .....	8
2.3 Cleaning the walls of the injector shaft.....	9
2.4 Cleaning the sealing surface of the injector shaft.....	11
<b>3. Module 1.1 - Brushing Plus .....</b>	<b>12</b>
3.1 Closing the bore to the combustion chamber .....	12
3.2 Careful cleaning of the shaft wall and sealing seat.....	12
<b>4. Module 2 - Milling .....</b>	<b>14</b>
4.1 Preparing the injector seat milling cutter .....	14
4.2 Placing the milling cutter in the injector shaft .....	15
4.3 Cleaning the seal seat in the injector shaft with the milling tool.....	16
4.4 Revising the sealing seat in injector shaft.....	17
4.5 Finishing.....	17
<b>5. Module 3 - Removing the sealing ring.....</b>	<b>18</b>
5.1 Preparing the sealing ring extractor.....	18
5.2 Removing the sealing ring.....	19
<b>Recommended accessories .....</b>	<b>20</b>



# UNIVERSAL INJECTOR SHAFT CLEANING KIT

9038100



## MODULE 1 - BRUSHING

9038010

- 1** 9039032 Wire Brush Ø 18 mm
- 2** 9039031 Wire Brush Ø 19 mm
- 3** 9039029 Wire Brush Ø 21 mm
- 4** 9039028 Wire Brush Ø 24 mm
- 5** 9039027 Wire Brush Ø 26 mm
- 6** 9039013 Silicon Carbide Endbrush Ø 14
- 7** 9039012 Steel Wire Endbrush Ø 17 mm
- 8** 9039036 Toolholder for Wire Brush
- 9** 9039008 Setting Tool with 6 Sealing Plugs with Collars Ø 8+10 mm
- 10** 9039034 Flexible Bit Holder ¼"
- 11** 9049027 Pipe Brush Ø 7,5 mm
- 12** 9039016 Guide For End Brush

## MODULE 1.1 - BRUSHING PLUS

9038011

- 1** 90390041 Injector Seat Cross Buffs Ø 19 mm, Fine
- 2** 9039004 Injector Seat Cross Buffs Ø 25 mm, Fine
- 3** 90390021 Injector Seat Cross Buffs Ø 19 mm, Coarse
- 4** 9039002 Injector Seat Cross Buffs Ø 25 mm, Coarse
- 5** 9039032 Wire Brush Ø 18 mm
- 6** 9039031 Wire Brush Ø 19 mm
- 7** 9039029 Wire Brush Ø 21 mm
- 8** 9039028 Wire Brush Ø 24 mm
- 9** 9039027 Wire Brush Ø 26 mm
- 10** 9039003 Toolholder for Cross Buff
- 11** 9049027 Pipe brush Ø 7,5 mm



## MODULE 2 - MILLING

9038020

- 1
**90390331** Injector Seat Milling Cutter  
180° Ø 15 : 17 mm
- 2
**90390340** Injector Seat Milling Cutter  
180° Ø 17 mm
- 3
**90390321** Injector Seat Milling Cutter  
120° Ø 17 : 18,8 mm
- 4
**9039049** Centring Cone  
Ø 16,7 - 22,0 mm
- 5
**90390493** Centring Cone  
Ø 17,8 - 20,6 mm
- 6
**90390495** Centring Cone  
Ø 18,8 - 24,5 mm
- 7
**9039046** Basic Device for Injector  
Seat Milling Cutter
- 8
**90390485** Depth Gauge
- 9
**60200035** Cutting Grease 300 g
- 10
**151.2103** Allen Key Ball End  
3 mm long



## MODULE 3 - EXTRACTING THE SEALING RING

9038030

- 1
**6039070** Universal Sealing  
Ring Extractor
- 2
**60390750** Slide Hammer 1.35 kg
- 3
**40103000** Flexible Lamp BAL



## SAFETY NOTICE

**To understand the functioning of the tools,  
is it necessary to read the manual in advance!**

- ▶ Read these instructions before assembling, during installation and throughout use and in the proper sequence.
- ▶ Always refer to the OEM manufacturer's instructions and service manuals for the latest data and to maintain the correct sequence.
- ▶ These work instructions and the recommended tools are meant to serve as aides only and are by no means a guarantee for certain results.
- ▶ This tool kit is a special collection and it has been tested and used successfully on several occasions.
- ▶ It is of the utmost importance to maintain the correct procedure as per the instructions.



The use of the tools should only be carried out by qualified personnel!

### Pictograms and their meaning



#### ATTENTION

Special caution



#### CORRECT



#### SPANNER

Hint or recommendation



#### FALSE



#### SAFETY GOGGLES

Wearing safety goggles necessary

## 1. PREPARATION

Remove fuel lines, electrical connectors and other components which will hinder the work.


Remove soot and slagging etc.



Remove the injector from the cylinder head with a suitable tool.



Tools to do this can be found in recommended accessories (page 20).




*Cylinder head cross section with soiled injector shaft*

## 2. MODULE 1 - BRUSHING



4



5

Cylinder head cross section

### 2.1 Cleaning the bore to the combustion chamber

Clean, with the pipe brush  $\varnothing$  7.5 mm, the bore to the combustion chamber **5**.



6



7

Cylinder head cross section

### 2.2 Closing the bore to the combustion chamber

Place using the setting tool **6** the appropriate plug (8 or 10 mm collar diameter) in the previously cleaned bore.

If the plug cannot be inserted easily, then reclean the bore with the pipe brush  $\varnothing$  7.5 mm



### 2.3 Cleaning the walls of the injector shaft

Measure the diameter of the removed injector **8** and select the appropriate wire brush (see table 1).

With stepped injectors, with large diameter differences, the wire brush has to be changed according to the diameter that has to be cleaned.

 The wire brush used should always be the same or next larger diameter.




Ø	
18 mm	9039032
19 mm	9039031
21 mm	9039029
24 mm	9039028
26 mm	9039027


Table 1: Selecting the appropriate wire brush

Clamp the selected wire brush in the brush holder with two spanners **14** & **13**.




Insert the brush holder into the flexible shaft, clamp the shaft in an electrical drill and place the brush in the injector shaft.







Cylinder head cross section



Cylinder head cross section

Clean the surface of the injector shaft at medium speed. 



Remove the loosened deposits with a vacuum cleaner or compressed air. 

In order not to remove the plug inadvertently this should be pinned down with the insertion tool. 



If the copper seal is already removed with the injector from the shaft, then continue with **step 2.4**.

Is the copper seal still in injector shaft, **18** it can be removed with module 3. (see page 18) 

But first must the previously set plug be removed. 

## 2.4 Cleaning the sealing surface of the injector shaft

In case of gross contamination is the injector shaft sealing surface first cleaned with the Steel End Brush and finished with the Silicon Carbide Brush.

Insert the end brush into the flexible shaft. Slide the guide over the flexible shaft and end brush.



Clamp the shaft in an electrical drill. Insert, by aided by the guide, the end brush in the injector shaft.

When cleaning, do not use excessive force or speed, as this could damage the sealing surface for the injector.

Remove gross contamination with the Steel End Brush, in case of only light contamination will the more gentle Silicon Carbide End Brush suffice. Repeat the cleaning process until the sealing seat is shiny clean. Repeat the process until the sealing seat shines.

**22**

The sealing seat can be examined on cleanliness with the flexible lamp from **module 3**.




Cylinder head cross section




Clean as previously described the shaft with a vacuum cleaner or compressed air. (see fig. **15** & **16**)

Remove the plugs with the insertion tool and clean again the sealing seat shortly with the end brush.

Again clean the shaft with a vacuum cleaner or compressed air.



Cylinder head cross section



Cylinder head cross section


### 3. MODULE 1.1 - BRUSHING PLUS



**ATTENTION:** Before module 1.1. is used, all steps of module 1 - Brushing should have been carried out.



27



28

Cylinder head cross section

#### 3.1 Closing the bore to the combustion chamber

Place using the setting tool **27** the appropriate plug (8 or 10 mm collar diameter) in the previously cleaned bore.



29

	Ø	
Coarse	19 mm	90390021
	25 mm	9039002
Fine	19 mm	90390041
	25 mm	9039004


Table 2: Selecting the proper Cross Buff

#### 3.2 Careful cleaning of the shaft wall and sealing seat

Select the right Cross Buff depending on the injector diameter. Clean off heavy grime first with the coarse Cross Buff, later change to the fine.



30




31

Screw the selected Cross Buff on the Cross Buff holder and insert it into the flexible shaft.



Clamp the flexible shaft into the drill and clean the wall and the sealing seat with medium speed to a high gloss. **Work only clockwise!**

Clean repeatedly the shaft with a vacuum cleaner or compressed air. (see fig. 15 & 16)



Cylinder head cross section




Cylinder head cross section



Remove the plugs with the insertion tool and repeat cleaning the sealing seat shortly with the Cross Buff.

Clean the shaft with a vacuum cleaner or compressed air. (see fig. 15 & 16)



Cylinder head cross section



Cylinder head cross section



Wasn't it possible to remove all impurities from the sealing seat or damage is visible (Pits or burned exhaust residues, etc.) and this may prevent sealing of the injector, is it possible to revise the sealing seat precise and controlled with the tools of module 2.



## 4. MODULE 2 - MILLING




Cone	Ø in mm	
A	16,7 - 22	9039049
B	17,8 - 20,6	90390493
C	18,8 - 24,5	90390495

Table 3: Selecting the proper cone brush



### 4.1 Preparing the injector seat milling cutter

Select the appropriate, depending on the injector shaft opening, centring cone and slide it together with the depth stop on the basic device.



Cutter	Ø in mm	
A 120°	17 : 18,8	90390321
B 180°	15 : 17	90390331
C 180°	17 mm	90390340

Table 4: Selecting the proper milling cutter

Select the appropriate injector seat milling cutter by comparing it with the bottom side of the injector.



Slide it flush on to the basic device and make sure, that it's clamped on the flat spot of the basic device.



To bond the chips and for a better cutting result, immerse the milling cutter slightly rotating clockwise into the cutting grease.

## 4.2 Placing the milling cutter in the injector shaft

Insert the milling cutter in the injector shaft and lightly knock the centring cone in with the depth stop.



Make sure that the copper sealing ring and the sealing plug previously have been removed.




Should the depth stop sit too close to the cylinder head, can a second centring cone be slid on the basic device as a spacer.

e.g. with the PSA DV4 engine.




Retain the upper scale ring and turn the lower ring on the depth stop so long in a **clockwise direction**, until the stop. **50**

Now turn the adjusting ring as long **counter clockwise** until its zero position lines up with the mark on the upper scale ring. **51**




Push the injector seat milling cutter all the way in, press the depth stop on the centring cone and at the same time clamp the upper scale ring.

Then clamp the lower setting ring.





Cylinder head cross section



### 4.3 Cleaning the seal seat in the injector shaft with the milling tool

By gently pressing the basic device and rotating it clockwise, clean the injector seal seat surface.



Remove the injector shaft milling cutter and check if the seal seat is clean.

Suitable accessories for this can be found on page 20 or in **module 3 (flexible lamp)**.

If necessary, release the lower ring, and add 0.05 mm. Repeat steps 54 to 59 as long as necessary until all deposits are removed

**Clean and regrease the milling cutter several times.**



Could all impurities be eliminated, then **continue with step 4.5**.

Shows the sealing seat damages such as pits, burned in exhaust deposits, etc., then **continue with step 4.4**.

#### 4.4 Revising the sealing seat in injector shaft

Could not all impurities be eliminated or shows the sealing seat damages such as pits or burned in exhaust deposits, then this can be rectified with the injector seat milling cutter. For that purpose material is removed by milling until all damages are removed. See steps 54 to 59.

Depending on how much material had to be removed, an **oversize sealing ring** can or must be used.

**Follow the manufacturer's instructions!**



By means of the used the depth gauge can exactly be adjusted how much material is to be removed or determined how much has been removed.

Original sealing ring: 1.20 mm

Oversize sealing ring: 1.55 mm

this gives; add 0.35 mm.



#### 4.5 Finishing

Clean again the sealing seat with the fine Cross Buff.



Before installing the new injector, the engine can be cranked over once shortly.

Thus, the last residual debris will be removed by the compression from the injector shaft.



*Cylinder head cross section*



## 5. MODULE 3 - REMOVING THE SEALING RING



66

### 5.1 Preparing the sealing ring extractor

The knurled actuator of the sealing ring extractor must be freely movable and should have 3 - 4 mm play from the knurled pipe.



67



68

After being used several times it can happen that the four claw elements get overstretched and do not fit in the sealing ring anymore. This can be corrected by squeezing them together with a pair of long-nosed pliers.



69




70

Use a new sealing ring and place it on the extraction claw in order to adjust the grip depth.



71



72

The claw is optimally adjusted when the collar protrudes minimally over the sealing ring.

If the claw protrudes too much, it will jam in the bore for the nozzle.

If the claw protrudes too little, it will not grip the sealing ring properly.



## 5.2 Removing the sealing ring

Screw the slide hammer on the sealing ring extractor and place the combination in the injector shaft.



Tap gently with the slide hammer the extractor claw of the sealing ring extractor into the bore of the sealing ring.



Cylinder head cross section

By turning the knurled actuator clockwise spread open the claw of the sealing ring extractor and grab this way the sealing ring.



Cylinder head cross section

By tapping gently with the slide hammer remove the sealing ring from the injector shaft.



## RECOMMENDED ACCESSORIES

### Universal Injector Removal Set II



60384435

### Injector Adapter Set

15 pc



60384660


### Slide Hammer

8,5 kg



6148800

### Universal Hydraulic Injector Removal Tool



60385445

### Injector Removal Toolkit

Renault M9R/M9T Engine

- with Hydraulic Hollow Piston Cylinder
- Especially for torn injectors



60385095

### Extractor Claw

for the Sealing Ring Extractor



6039072

### Countersink Screw

for the Sealing Ring Extractor



6039071

### Videoscope „EXCLUSIVE“



9078050

### Flexible Magnetic Pick-Up



52601020

### Universal Injector Sealing Ring Assortment 450 pc



60390505

### Universal Injector Sealing Ring Assortment

With 19 different washers, clips and connectors



60390605

### Injector Removal Set SOFIM



60385345

### Glowplug Hole Brushes Set

14 pieces



90490300

### Injector Needle Puller



6038472E

### Hydraulic Set 3 pieces

700 bar



80255500





## ÖSTERREICH

✉ info@pichler-werkzeug.com  
☎ +43 512 344552

PICHLER Werkzeug GmbH & CoKG  
Pacherstrasse 20  
A-6023 Innsbruck

## DEUTSCHLAND

✉ info@pichler-werkzeug.de  
☎ +49 8821 6869780

PICHLER Werkzeug GmbH  
Zugspitzstrasse 33  
D-82467 Garmisch-Partenkirchen

## SCHWEIZ

✉ pichler@werkzeugag.ch  
☎ +41 61 981 33 55

PICHLER Werkzeug AG  
Rünenbergerstrasse 31  
CH-4460 Gelterkinden

## FRANKREICH

✉ pichler@pichler.fr  
☎ +33 389551596

PICHLER Outillage Sàrl  
19a, rue de Reiningue  
F-68310 Wittelsheim

## GB & IRLAND

✉ office@pichler-tools.com  
☎ +44 1335 360759

PICHLER TOOLS LTD  
Ednaston Business Centre  
Hollington Lane, Ednaston  
Ashbourne · DE6 3AE

## BELGIEN

✉ belgique@pichler.fr  
☎ +32 495 400810

PICHLER Outillage BVBA  
Industrieweg 45  
B-8800 Roeselare